

A IMPORTANT INSTRUCTIONS

START
HERE

For Opening and Re-sealing fixture with flush lid

Warning: The Luminaire should only be used complete with its protective shield (cover)
All connections must be kept dry; failure to do so may result in product reliability issues

Lumascap Lighting Industries Pty Ltd
38-44 Enterprise Street, Cleveland, QLD 4163, Australia
PO Box 1875, Cleveland D.C., QLD 4163, Australia
T 07 3286 2299
F 07 3286 6599
E sales@lumascap.com.au
W www.lumascap.com.au

Thank you for taking the time to read this, it will save you time and money.

First, some simple rules.

- Do not use your battery drill
- Do not use silicone sealant
- Keep all surfaces clean
- Keep all foreign material out of the fixture

1



1. Clear area around fixture of loose dirt and debris, and wipe the fixture off with clean rag

2



2. Clean out socket head screws with a small pointed object

3



3. Ensure allen-key is in good condition and loosen each screw one turn only, repeat once again and then just remove each screw

4



4. Use allen-key to lift off cover

5




5. Place lid up-side-down on clean rag

6



6. Clean out rim, remove any foreign objects from fixture

7



7. Run Fixture.

Allow to burn for 10-15 minutes without lid attached to allow any moisture in fixture to evaporate.

Further information over page





www.lumascap.com.au

B IMPORTANT INSTRUCTIONS

For Opening and Re-sealing fixture with flush lid


Warning: The Luminaire should only be used complete with its protective shield (cover)
All connections must be kept dry; failure to do so may result in product reliability issues

Lumascap Lighting Industries Pty Ltd
38-44 Enterprise Street, Cleveland, QLD 4163, Australia
PO Box 1875, Cleveland D.C., QLD 4163, Australia
T 07 3286 2299
F 07 3286 6599
E sales@lumascap.com.au
W www.lumascap.com.au




NOTE: Do not attempt to tighten any one screw fully. This will take longer and will not seat the seal properly.

6 Screw Torque Pattern



4 Screw Torque Pattern



www.lumascap.com.au

IMPORTANT SAFETY INSTRUCTIONS

WARNING - To reduce the risk of FIRE or INJURY:

1. Luminaires and transformers to be installed by qualified installers only.
2. Luminaires to be used for intended purpose only. e.g Wall Mount fittings must be wall mounted.
3. Luminaires can become very hot. Use discretion in placement.
4. Do not touch hot lens, guard, or enclosure.
5. CAUTION - HOT SURFACE. Keep away from curtains and other combustible material.
6. Turn Off/Unplug and allow to cool before replacing lamp.
7. Keep lamp away from materials that may burn.
8. Never touch lamp with bare fingers. Oil from skin may damage lamp. Hold lamp with soft cloth when installing or replacing.
9. Do not operate the luminaires with a missing or damaged parts.
10. Replace any cracked protective shield
11. Use only lamp type, voltage and wattage as specified by Lumascape on the product label.
12. Use only genuine Lumascape parts to replace damaged or missing components.
13. Luminaires supplied with Loctite Silver Grade Anti Seize lubricant on threads. Reapply if needed.
14. Refer to instructions for installation and operating requirements.
15. Ensure installation complies with local regulations

SAVE THESE INSTRUCTIONS.

LUMASCAPE
 HEAD OFFICE - QLD
 Tel (07) 3286 2299
 Fax (07) 3286 6599

LUMASCAPE
 SYDNEY - NSW
 Tel (02) 9519 6860
 Fax (02) 9519 8834

LUMASCAPE
 MELBOURNE - VIC
 Tel (03) 9686 1900
 Fax (03) 9686 1700

LUMASCAPE USA INC.
 SAN FRANCISCO - CA
 Tel 1-(650)-595-5862
 Fax 1-(650) 595-5820

H.I. LIGHTING
 LUMASCAPE AGENT - WA
 Tel (08) 9321 5422
 Fax (08) 9321 5881

LIGHTING PARTNERS AUSTRALIA
 LUMASCAPE AGENT - SA
 Tel (08) 8232 0074
 Fax (08) 8232 0076

NQ LIGHTING
 LUMASCAPE AGENT - NTH QLD
 Tel (07) 4031 4490
 Fax (07) 4031 5933

ECC LIGHTING
 LUMASCAPE AGENT - NZ
 Tel (09) 379 9680
 Fax (09) 308 9328