

ACCESSORY FOR

Q2 Q4 Q6 Q8


INSTALLATION INSTRUCTIONS

SHIELDING & GLARE CONTROL
QUADRALUX RANGE



LUMASCAPE

USA | Australia | Asia | Middle East | Europe



Accessory Holder
Required for the attachment of any accessory.

Cross Hatch Louvre
Always comes in black colour.

45° Visor

SELECT INSTALLATION

- Cross Hatch Louvre Only ▶ Go to Section A
- 45° Visor Only ▶ Go to Section B
- Cross Hatch Louvre + 45° Visor ▶ Go to Section C

Luminaire Code	Accessory Holder	Cross Hatch Louvre	45° Visor
Q2 - LS9120	LS6201	LS6202	LS6203
Q4 - LS9140	LS6205	LS6206	LS6207
Q6 - LS9160	LS6222	LS6223	LS6224
Q8 - LS9180	LS6226	LS6227	LS6228

There are a variety of shielding and glare control options available for Lumascape's Quadralux range. Even though the different luminaires within the Quadralux range differ in size, the installation process for the shielding and glare control accessories is the same for all of them. The table on the left lists the accessory codes for each luminaire type.

READ ALL SAFETY INSTRUCTIONS FIRST

- > Follow instructions carefully, failure to do so will void warranty.
- > Luminaire is factory sealed, opening luminaire will void warranty

LUMASCAPE ASIA PACIFIC Brisbane Technology Park, 18 Brandl Street, Eight Mile Plains, QLD 4113, Australia
Phone +61 7 3854 5000 | Fax +61 7 3854 5001 | Email: sales@lumascape.com.au | www.lumascape.com


LUMASCAPE NORTH AMERICA 1300 Industrial Road, Unit #19, San Carlos, CA 94070, USA
Phone +1 650 595 5862 | Fax +1 650 595 5820 | Email: info@lumascape.com | www.lumascape.com

Products and specifications are subject to change without notice.




Section A - Install Cross Hatch Louvre Only

Slide louvre into accessories holder. Make sure all the components have the right orientation and alignment as shown below.



Slip the accessory holder & louvre assembly over the luminaire



ACCESSORY FOR

Q2 Q4 Q6 Q8

INSTALLATION INSTRUCTIONS


SHIELDING & GLARE CONTROL
QUADRALUX RANGE



LUMASCAPE


USA | Australia | Asia | Middle East | Europe

Insert the four screws to hold the assembly in place.



NOTE: Do not remove any screws from the luminaire body to secure the accessory holder.


Completed Assembly






Section B - Install 45° Visor Only

Slide 45° visor into accessories holder. Make sure all the components have the right orientation and alignment as shown below.



Slip the accessory holder & 45° visor assembly over the luminaire.



ACCESSORY FOR

Q2 Q4 Q6 Q8

INSTALLATION INSTRUCTIONS


SHIELDING & GLARE CONTROL
QUADRALUX RANGE



LUMASCAPE


USA | Australia | Asia | Middle East | Europe

Insert the four screws to hold the assembly in place.



NOTE: Do not remove any screws from the luminaire body to secure the accessory holder.

Completed Assembly




Section C - Install Cross Hatch Louvre + 45° Visor


Make sure all the components have the right orientation and alignment as shown below.

Slip cross hatch louvre into 45° visor at an angle as shown.

Rotate the cross hatch louvre into place as shown below.



Slide 45° visor and louvre assembly into accessories holder. Make sure all the components have the right orientation and alignment as shown below.



ACCESSORY FOR

Q2 Q4 Q6 Q8

INSTALLATION INSTRUCTIONS


SHIELDING & GLARE CONTROL
QUADRALUX RANGE




LUMASCAPE

USA | Australia | Asia | Middle East | Europe

Slip the accessory holder, 45° visor and louvre assembly over the luminaire.



Insert the four screws to hold the assembly in place.



NOTE: Do not remove any screws from the luminaire body to secure the accessory holder.

ACCESSORY FOR

Q2

Q4

Q6

Q8

INSTALLATION INSTRUCTIONS

SHIELDING & GLARE CONTROL


QUADRALUX RANGE



LUMASCAPE

USA | Australia | Asia | Middle East | Europe

Completed Assembly



? **QUESTIONS** Contact us at details below.

LUMASCAPE ASIA PACIFIC Brisbane Technology Park, 18 Brandl Street, Eight Mile Plains, QLD 4113, Australia
Phone +61 7 3854 5000 | Fax +61 7 3854 5001 | Email: sales@lumacape.com.au | www.lumacape.com

LUMASCAPE NORTH AMERICA 1300 Industrial Road, Unit #19, San Carlos, CA 94070, USA
Phone +1 650 595 5862 | Fax +1 650 595 5820 | Email: info@lumacape.com | www.lumacape.com

Products and specifications are subject to change without notice.